

Scramble Egg

CONNECTING DIAGRAM

SOLDER SIDE		PARTS SIDE	
SIGNAL NAME	PIN No.	SIGNAL NAME	
-5V	A 1	B 1	+12V
SPEAKER (GND)	A 2	B 2	SPEAKER
1P SHOOT	A 3	B 3	1P UP
1P RIGHT	A 4	B 4	1P LEFT
1P START	A 5	B 5	2P START
2P SHOOT	A 6	B 6	2P UP
2P DOWN	A 7	B 7	
2P LEFT	A 8	B 8	2P RIGHT
COIN COUNTER 2	A 9	B 9	1P DOWN
COIN 2	A10	B10	COIN 1
	A11	B11	COIN COUNT 1
	A12	B12	
VIDEO GREEN	A13	B13	VIDEO BLUE
VIDEO RED	A14	B14	VIDEO SYNC
	A15	B15	
GND	A16	B16	GND
GND	A17	B17	GND
+5V	A18	B18	+5V

